

Carson® Universal Display Assembly

PARTS LIST:

- base
- 3 pole sections
- 6 arms
- Carson header
- 6 screws & allen wrench
- 2 wing-nut screws
- 4 wheels
- wrench

TO ASSEMBLE:

- (1) Screw wheels into the bottom of the Base using the enclosed wrench.
- (2) Place base with wheels on the floor.
- (3) Place the bottom of the pole into the center of the base.
- (4) Secure the pole into place by tightening the wing nut screws.
- (5) Take middle section of the pole and screw onto bottom section.
- (6) Take upper section of the pole and screw onto the middle section.
- (7) Place arms into brackets, then secure with screws and allen wrench that is provided.
- (8) Place Carson header into upper pole section.

CAUTION:

- When tightening screws, do not over tighten or they may strip out.
- Some sections may have a snug fit and slight force may be necessary in order to have the pieces fit correctly together.
- Distribute chimes evenly to prevent the display from tipping or leaning.

