

63730 A-Frame Garden Stone Display Assembly Instructions

List of Parts

Frame Pieces

1 A-Frame



2 Cross Bars



2 Swivel Casters



2 Swivel-Locking Casters



16 Shelves



Hardware

1 Wrench



4 Bolts



Directions

1. Remove from carton and check the parts list for missing pieces.
2. Lay **A-Frame** on its side, spread apart.
3. Using the **wrench** and **4 bolts**, bolt the **Cross Bars** to the **A-Frame**.
4. While keeping **A-Frame** on its side, install the **2 Swivel-Locking Casters** to one end by pushing the caster pin into the bottom of the **A-Frame** leg. If needed, a soft rubber mallet may be used to ensure caster is securely in place.
5. On the opposite end, install the **2 Swivel Casters** using the same installation method as listed in step #4.
6. Stand the **A-Frame** upright, and lock the **2 Swivel-Locking Casters**.
7. Hang the **16 Shelves** as shown in the image to the right.

Your display is now assembled and ready to be filled with Carson® product!

