

## 70003 Counter Top Wire Coaster Display

### List of Parts

#### Frame Pieces

- 1 Base Stand w/ 5 Feet (A)
- 1 Post w/ Female Threaded Bottom & Male Bolt Top (B)
- 1 Post Clamp w/ 2 Wingnuts (C)
- 2 Rack Holders (D)
- 1 Post w/ Female Threaded Bottom and Hollow Top (E)
- 1 Set of Bearings (F)
- 1 Display Cap (G)
- 4 Racks (H)

#### Hardware

- 1 Wrench
- 1 Bolt

### Directions

1. Take the **Base Stand (A)** and attach the **5 Feet** thru the bottom of the legs.
2. Place **Post w/ Female Threaded Bottom & Male Bolt Top (B)** into center opening of **Base Stand (A)** w/ Female Threaded Bottom facing downward. Then, screw the bolt to the post from underneath the **Base Stand (A)**.
3. Take **1 Post Clamp w/ Wingnuts (on bottom) (C)** and slide it down the **Post (B)** and fix it about a foot above the **Base Stand (A)**. Then, take **1 Rack Holder (flat side down) (D)** and slide it down the **Post (B)**, where it will rest on top of the **1 Post Clamp (C)**.
4. Take **1 Post w/ Female Threaded Bottom and Hollow Top (E)** and attach it to the bottom **Post (B)**. Then, slide the **Set of Bearings (F)** down the **Post (E)** and let it sit on top of the welded clamp. Slide second **Rack Holder (flat side down) (D)** down the top **Post (E)** and let it sit on top of **Bearings (F)**.
5. Now, individually set a **Rack (I)** on each side of the top **Rack Holder (D)** bars with the brace bar. Once, each rack is hanging from the top, slide the bottom **Rack Holder (D)** above the bottom brace bars and then slide it back over the brace bars to fix the **Racks (H)**.
6. Finally, attach the **Display Cap (G)** on top of the **Post (E)**.

Your display is now assembled and ready to be filled with Carson® product!

