

CAR COASTER SETS DISPLAY

INSTRUCTIONS

1. Insert 3 legs (A) into back piece (C).
2. Insert 2 supports (B) into back piece (C).
3. Stand upright on flat surface.
4. Insert 6 hooks (D) on each side into slots.

INCLUDES:

- (A) Legs (3)
- (B) Supports (2)
- (C) Back Piece
- (D) Hooks (12)

